



Item	Parts No.	Parts Name	Ref.Picture
1	2002000021	KA-300 MOTO3 A40 game box	
2	1021000004	KA-300 MOTO3 17inch LCD	
3	1026000008	KA-300 MOTO3 17inch LCD driver board	
4	2001000148	KA-300 MOTO3 17inch LCD constant current board	
5	1029000180	KA-300 MOTO3 Joy stick cover	
6	1042000481	KA-300 MOTO3 speed up stick	
7	1042000482	KA-300 MOTO3 brake stick	
8	1010000022	KA-300 MOTO3 start button	
9	2001000025	KA-300 MOTO3 setting keyboard	
10	2001000008	KA-300 MOTO3 tire LED PCB board	
11	2001000146	KA-300 MOTO3 Direction sensore converter board	
12	1026000019	KA-300 MOTO3 Power supply 12V, 16.5A	
13	1040000039	KA-300 MOTO3 bearing	
14	1029000181	KA-300 MOTO3 LCD frame box	
15	1042000449	KA-300 MOTO3 decoration nameplate	
16	1023000054	KA-300 MOTO3 base board decoration PC	
17	1023000049	KA-300 MOTO3 baffle	
18	1023000052	KA-300 MOTO3 dash board PCB	
19	1029000182	KA-300 MOTO3 dash board cover	

20	1005010009	KA-300 MOTO3 head LED	
21	1017000003	KA-300 MOTO3 Speaker	
22	1045000006	KA-300 MOTO3 Speaker cover	