


# Smart train

Parts No.	Parts Name	Ref.Picture
2003000037	KA-60/120/130/170/220/230/500 Kiddie ride steering wheel	
2002000001	KA-60/120/130/140/150/160/170 S3 game box	
1046000003	Motor for MSKY all kiddie ride 220V 60B 50W	
1043000008	KA-60/120/130/140/150/160/170 Motor gear	
1040000004	UCP 203 for MSKY all kiddie ride	
1042000339	KA-130 17inch LCD moduel metal plate	
1021000003	KA-130 17inch monitor	
2001000004	KA-130 17inch Driver board	
1029000059	KA-130 17inch LCD frame	
1038000002	KA-130 LCD Lock	
1020200008	KA-130 17inch LCD cable	
2005000002	KA-130 Power supply	
1005010046	KA-130 Green LED	
1005010022	KA-130 Red LED	
1045000016	KA-130 Pedal	
1031000016	KA-130 rubber damper	
2001000012	KA-130 flash LED	
1029000002	KA-130 Round LED plastic cover	

1020000040	KA-130 Steering wheel cable	
1020000064	KA-130 Speaker cable	
1020000087	KA-130 Coin acceptor cable	
1020000029	KA-130 Colorful LED cable	
1015000012	KA-130 5pin socket	
1020000072	KA-130 Motor cable	
1020100002	KA-130 220V power cable	
1020000084	KA-130 2pin LED cable	
1020000058	KA-130 2pin SM male cable	